

Thank you for purchasing the CRICKET BELL.

Please read the following instructions thoroughly before attempting to install this product.

Proper installation is required for safe riding. Contact us or a bike mechanic if you need further assistance with certain steps.

CONTENTS

· Cricket bell	----- 1 UNIT	· 31.8mm spacer ring	----- 1 PC
· 22.2mm spacer ring	----- 1 PC		

FITTING




1. Cricket bell fits 35mm, 31.8mm, and 22.2mm handlebar diameters. Apply the correct spacer configuration in accordance with your handlebar diameter.



31.8mm spacer





22.2mm spacer





INSTALLATION AND USE

1. Place the bell onto the handlebar with the proper spacer and tighten the bell with a 3mm hex key.




⚠ Please Note: The bell may interfere with the frame's top tube, especially if positioned close to the stem. You should ensure that your bike's steering is not restricted in any way before riding.

2. Switch between cowbell mode and single-strike mode by pulling down or pushing up on the bell body.



SINGLE-STRIKE MODE



COWBELL MODE