

Thank you for purchasing the QUICKIE PUMP HEAD.


Please read these instructions thoroughly before attempting to install this item.
Proper installation is required for safe riding. Contact us or a bike mechanic if you are not sure with certain steps.

CONTENT


· Quickie Pump Head 1 PC

INSTALLATION

Compression Nut Type : Cut the pump hose cleanly to remove your existing pump head. Slide the compression nut onto the bare hose, push the hose firmly over the tapered inner insert, and tighten the compression nut securely.




Schrader Thread Type : Simply align the Quickie adapter with your existing Schrader pump connection. Screw the adapter clockwise and hand-tighten firmly.




HOW TO USE


1. The Granite Quickie accepts all three valve types. Presta and Clik share one port, while Schrader uses a separate port, as illustrated.
Twist the knob to switch between Presta and Clik.



2. Push the Quickie onto the valve to begin pumping. Do not press the quick-release knob while connecting.





3. Once inflation is complete, press the quick-release knob to release the pump head from the valve.




CAUTION !

1. The Presta valve should protrude at least 15mm from the rim to ensure proper engagement.
2. If your tire or tube contains sealant, rotate the wheel so the valve sits at 90°. Press the valve for a few seconds to eject any sealant before connecting. This prevents sealant from entering and damaging the pump head.




O-RING REPLACEMENT


1. Remove the cap using a 6mm hex key.



2. Inside the pump head bore, you'll find an inner seal. Use tweezers to gently remove it.



3. Place the O-ring into its designated slot as shown in the illustration and pay attention to directionality.



4. Reattach the cap using a 6mm hex key.

